

FAMILY ACTIVE STACK

Product Manual

Product Name:	Family Active Stack
Materials:	Storage Containers, Storage Container Lids - Food-Grade Silicone Storage Box, Storage Box Cover - Food-Grade PP Recording Cards - Kraft Paper
Colours:	Pea Green / Blush
Dimensions:	100ml Silicone Storage Containers - 71 × 52 × 62mm 200ml Silicone Storage Container - 105 × 71 × 62mm 500ml Silicone Storage Container - 142 × 105 × 62mm PP Storage Box (with Containers) - 231 × 162 × 70mm Recording Cards - 35 × 34 × 0.5mm
Contents:	2 × 100ml Silicone Storage Containers with Lids 1 × 200ml Silicone Storage Container with Lid 1 × 500ml Silicone Storage Container with Lid 1 × PP Storage Box 20 × Recording Cards
Standard:	EN 14372

Product Description:

The Family Active Stack is a versatile collection containing a range of conveniently sized containers. It's kept together in a handy storage box to prevent mess during transport, or to be stored tidily away when not in use. Made from 100% food-grade silicone, the container lids stay secure, keeping food fresh and preventing spills.

Measurement marks on the side mean amounts can be checked easily, while the label slots allow for quick identification of contents and storage dates. The silicone containers are safe in freezers, ovens, microwaves and dishwashers.

The handy PP storage box is perfect for keeping your containers neat, tidy and mess-free when storing or transporting! Not only that - it can also be repurposed for use as a colander, fruit bowl, or more!


Features:

- The perfect option for contamination-free storage!
- Four 100% food-grade silicone containers across three sizes allow for a variety of uses.
- Storage Containers are made of soft and durable food-grade silicone.
- Secure silicone lids keep contents safe from contamination and spills.
- Measurement marks on the side of each container for easy portion control.
- Label slot for quick and easy identification of contents and storage date.
- The safe and non-toxic food-grade PP box keeps containers and their contents mess-free during transport.
- Silicone containers are safe in fridge/freezers, dishwashers, microwaves, sterilisers and boiling water.
- BPA, PVC and phthalate-free.


Cleaning and Care:

Before first use, disassemble and clean the product before placing silicone components in boiling water for 5 minutes to sterilise. Wash before and after each use. Remove recording cards before washing. Although dishwasher safe, we recommend hand washing with warm, soapy water and rinsing thoroughly. Other common methods of heating, cleaning, storage and use not listed in this manual may damage the product. Do not use any bleach-based cleaners or tablets to sterilise or clean your Haakaa products. To sterilise silicone components, use a steam steriliser or boil in water for 2-3 minutes. To sterilise plastic components, boil in water for no longer than 2-3 minutes. Do not use UV sterilisers to clean this product as it may impact the lifespan.

Lid with
easy-open lip



Container




Label Slot

2 × 100ml Silicone Storage Containers

Lid with
easy-open lip



Container




Label Slot

200ml Silicone Storage Container

Lid with
easy-open lip




Container




Label Slot

500ml Silicone Storage Container

Cover



Box Body



PP Storage Box

Caution:

For your child's safety and health WARNING!

Before each use, inspect the product. Throw away at the first sign of damage or weakness. Do not store near any sharp objects. Only soft bristle brushes or soft sponges should be used to clean this product, as hard scourers may scratch the surface. Please do not put the recording cards into sterilisers, microwaves or ovens. This product is not a toy. For your child's safety, never attach product to cords, ribbons, laces or loose parts of clothing, as it can become wrapped around their neck. Do not use this product for anything other than its intended use. Always use this product with adult supervision. Store product in a cool, dry place and avoid direct sunlight. Allow hot foods and liquids to cool before storing. When freezing foods and liquids, ensure container is not filled above top measurement mark as contents may expand when frozen. Do not forcefully shake the containers or store on their side while they contain liquid, as this may cause contents to leak. Always use a towel or oven mitts when removing containers from oven/microwave. Take lid off containers when heating, baking or sterilising. PP Storage Box is not suitable for long-term storage in freezers. PP Storage Box is not oven safe - heat food in microwave only and should not be heated continuously for more than 5 minutes.

PLEASE NOTE: Volume measurements are an approximation and should be used for general reference only. Take extra care when microwave heating; localised overheating can occur. Always mix the heated food and check the temperature before feeding. It is not recommended to keep infant food/breast milk frozen for longer than three months unless in a deep freeze. Always follow your country's guidelines on expressing and storing breast milk safely, ensuring you have labelled your container with date of expressing for easy identification. Do not re-freeze thawed food, breast milk or formula. Solid food is recommended for babies 4-6 months+. Please consult a medical professional if introducing solids earlier.